


Quick-Start-Guide STKa335x

Arm® architecture



VISIT OUR SUPPORT WIKI
support.tq-group.com



i Hardware Setup

- 1 Debug/Serial
- 2 SD-Card
- 3 DIP-Switches
- 4 Power

CONNECT STARTERKIT TO HOST PC

Connect STKa335x using the provided Micro USB cable to connect interface X15 to a USB port on the host. A USB serial driver might be required on the host to operate with the Starterkit. Detailed instructions are available on the STK Quicksteps Wiki page.

RUN TERMINAL EMULATOR AND CONFIGURE SERIAL PORT

After connecting the STKa335x, one new serial port is available on the host. this port is for the U-Boot / Linux serial debug console.

A terminal emulator is required on the host (Tera Term is recommended). Configure the serial port using the settings from the table on the right.

Baudrate	115200
Data Bits	8
Parity	none
Stop Bits	1
Handshake	XON / XOFF

SUPPLY THE STARTERKIT WITH POWER

Connect the provided power supply to X26 on the STKa335x.

Caution when using a different power supply!

The Starterkit requires an input of **24V** and is designed to operate with a regulated power supply.

ESTABLISH SERIAL CONNECTION

The bootloader and operating system outputs are displayed in the terminal. Once the boot process is complete, log in to the system using the default user "root" without a password.

Quick-Start-Guide STKa335x


Arm® architecture




Boot device selection

The boot device must be selected with DIP switch **S2** accordingly.
By default, the STKa335x starts in SD card configuration.


Configuration SD card



Configuration eMMC



Configuration FlexSPI



For latest documentation, BSPs, etc. please visit:

tq-group.com/en/products/tq-embedded/arm-architecture/tqma335x
support.tq-group.com/tqma335x

Visit our Website:

tq-group.com/en/products/tq-embedded

CREATE A TICKET

Via the TQ-Embedded Helpdesk, you can easily create and manage various types of requests.

support.tq-group.com/helpdesk

