


Quick-Start-Guide STKa243xL

Arm® architecture



VISIT OUR SUPPORT WIKI
support.tq-group.com



i Hardware Setup

- 1 Debug/Serial
- 2 SD-Card
- 3 DIP-Switches
- 4 Power



Power Adapter
Not required with all carrier boards

CONNECT STARTERKIT TO HOST PC

Connect STKa243xL using the provided Micro USB cable to connect interface X2 to a USB port on the host. A USB serial driver might be required on the host to operate with the Starterkit. Detailed instructions are available on the STK Quicksteps Wiki page.

RUN TERMINAL EMULATOR AND CONFIGURE SERIAL PORT

After connecting the STKa243xL, two new serial ports are available on the Host. The first port is the MCU serial debug console.

A terminal emulator is required on the Host (Tera Term is recommended). Configure the serial port using the settings from the table on the right.

Baudrate	115200
Data bits	8
Parity	none
Stop Bits	1
Flow Control	none
New Line Char	CR+LF
Local Echo	Enabled

SUPPLY THE STARTERKIT WITH POWER

Connect the provided power supply to X40 on the STKa243xL.

Caution when using a different power supply!

The Starterkit has a wide range input from **16V** to **26V** and is designed to operating with a regulated power supply.

ESTABLISH SERIAL CONNECTION

The bootloader and operating system outputs are displayed in the terminal. Once the boot process is complete, log in to the system using the default user "root" without a password.

Quick-Start-Guide STKa243xL


Arm® architecture




Boot device selection

The boot device must be selected with DIP switches **S4, S5, S6 and S7** accordingly.
By default, the STKa243xL starts in SD card configuration.


Configuration SD card



Configuration eMMC



Configuration FlexSPI



! For latest documentation, BSPs, etc. please visit:
tq-group.com/en/products/tq-embedded/arm-architecture/TQMa243xL
support.tq-group.com/TQMa243xL

Visit our Website:
tq-group.com/en/products/tq-embedded

Visit the Quicksteps Page to get started:
https://support.tq-group.com/en/arm/tqma64xxl/mbax4xxl/stk_quicksteps

CREATE A TICKET

Through the TQ-Embedded Helpdesk, you can easily create and manage various types of requests.
support.tq-group.com/helpdesk

