


Quick-Start-Guide STKa91xxCA

Arm® architecture



VISIT OUR SUPPORT WIKI
support.tq-group.com



i Hardware Setup

- 1 Debug/Serial
- 2 SD-Card
- 3 DIP-Switches
- 4 Power

CONNECT STARTERKIT TO HOST PC

Connect STKa91xxCA using the provided Micro USB cable to connect interface X4 to a USB port on the host. A USB serial driver might be required on the host to operate with the Starterkit.

Detailed instructions are available on the STK Quicksteps Wiki page.

RUN TERMINAL EMULATOR AND CONFIGURE SERIAL PORT

After connecting the STKa91xxCA, four new serial ports are available on the host. The first port is the U-Boot / Linux serial debug console.

A terminal emulator is required on the host (Tera Term is recommended). Configure the serial port using the settings from the table on the right.

Baudrate	115200
Data Bits	8
Parity	none
Stop Bits	1
Handshake	XON / XOFF

SUPPLY THE STARTERKIT WITH POWER

Connect the provided power supply to X18 on the STKa91xxCA.

Caution when using a different power supply!

The Starterkit has a wide range input from **16V** to **30V** and is designed to operate with a regulated power supply.

ESTABLISH SERIAL CONNECTION

The bootloader and operating system outputs are displayed in the terminal. Once the boot process is complete, log in to the system using the default user "root" without a password.

Quick-Start-Guide STKa91xxCA


Arm® architecture




Boot device selection

The boot device must be selected with DIP switch **S1** accordingly.
By default, the STKa91xxCA starts in SD card configuration.


Configuration SD card



Configuration eMMC



Configuration FlexSPI



For latest documentation, BSPs, etc. please visit:

tq-group.com/en/products/tq-embedded/arm-architecture/tqma91xxca
support.tq-group.com/tqma91xxca

Visit our Website:

tq-group.com/en/products/tq-embedded

Visit the Quicksteps page to get started:

https://support.tq-group.com/en/arm/tqma91xxca/mba91xxca/stk_quicksteps

CREATE A TICKET

Via the TQ-Embedded Helpdesk, you can easily create and manage various types of requests.

support.tq-group.com/helpdesk

