


Quick-Start-Guide STKxE39M

x86 Architecture



A

CONNECT EXTERNAL DISPLAY

Use DisplayPort connector X5 on the MB-COME10-1 to connect an external display (e.g. monitor).

B

CONNECT KEYBOARD AND MOUSE

Connect a keyboard and mouse to any USB port available on Connector X3 so that you are able to navigate in the UEFI/BIOS menu or in the OS.

C

SUPPLY THE STKxE39M WITH POWER

Double-check the mains voltage required for the included power supply (100V...240V), then connect it to connector X10 on the MB-COME10-1 using the included power adapter cable.

Caution when using a different power supply!

The Starterkit requires a regulated supply voltage of 12 V!

D

ACCESSING THE UEFI/BIOS

In order to get into the UEFI/BIOS menu press "Esc" on the connected keyboard as soon as the "TQ" corporate logo appears.

!

For latest documentation, Drivers, etc. please visit:

[tq-group.com/en/products/tq-embedded/x86-architecture/tqmxe39m](https://www.tq-group.com/en/products/tq-embedded/x86-architecture/tqmxe39m)

support.tq-group.com/tqmxe39m