


Quick-Start-Guide TQMa8MPxL



RAS314 Board



1 CONNECT HOST PC AND STKNAME

Use the supplied micro USB cable to connect X4 of the MBa8MP-RAS314 to a USB port on your host. You will find two serial ports on the host PC (one for the debug output (Linux / U-boot) and one for the board controller output).

RUN TERMINAL EMULATOR AND CONFIGURE SERIAL PORT

Run your favourite terminal emulator on the host PC (we recommend Tera Term Pro) and configure the serial port.

Baudrate	115200
Data bits	8
Parity	none
Stop bits	1
Handshake	XON/XOFF

2 SUPPLY THE STK WITH POWER

Double-check the mains voltage required for the included Power supply, then connect it to connector X18 on the MBa8MP-RAS314. Caution when using a different power supply! The Starterkit Can be operated using a regulated supply voltage of **12V!**

ESTABLISH SERIAL CONNECTION

The boot messages of boot loader and operating system are displayed by the terminal emulator. When the kit has fully booted you can log in to the system with the username **root**.

! For latest documentation, BSPs, etc. please visit:

tq-group.com/en/products/tq-embedded/arm-architecture/mba8mp-ras314

support.tq-group.com/mba8mp-ras314

Quick-Start-Guide TQMa8MPxL



RAS314 Board

Boot device selection

To select the desired boot device set DIP switch **S4** accordingly.

Configuration SD-Card

	S4			
DIP	1	2	3	4
Set	ON	ON	OFF	OFF

Configuration eMMC

	S4			
DIP	1	2	3	4
Set	OFF	ON	OFF	OFF

Configuration FlexSPI

	S4			
DIP	1	2	3	4
Set	OFF	ON	ON	OFF